



SERVUS^{LTD.}
TOTAL FACILITIES MANAGEMENT

SaniPod[™]

**A FIRST-CLASS EXPERIENCE
IN SANITARY NAPKIN DISPOSAL**



ACCORDING TO THE WORLD HEALTH ORGANISATION, WOMEN MAKE UP AT LEAST 42% OF THE ESTIMATED GLOBAL WORKFORCE – AND THAT FIGURE IS RISING – SO SERVUS IS INTRODUCING AN INNOVATIVE WAY FOR COMPANIES TO CONSIDER THEIR FEMALE STAFFERS' NEEDS.

SaniPod™

WHEN IT COMES TO FEMININE HYGIENE DISPOSAL, CONVENIENCE, CLEANLINESS AND CONSIDERATION ARE KEY TO A GREAT EXPERIENCE. SERVUS IS RAISING THE BAR WHEN IT COMES TO WASHROOM SERVICES IN THE WORKPLACE.

Servus' SaniPods are a stylish solution to the sensitive problem of sanitary product disposal. Traditional bins can be clunky, unsightly and prone to contamination – isn't that time of the month inconvenient enough? SaniPods allow working women to get through their day hygienically, responsibly and effortlessly!

These contemporary, wall-mounted pods are so compact that they are perfect for space-challenged washrooms or high-traffic bathrooms. They are super-easy to open, without pesky trays that make it cumbersome to dispose of waste; at the same time, it's difficult to see inside – a real win/win situation!

Best of all, Servus will supply, install and service the SaniPods. Because our units are smaller than typical sanitary bins, we refresh them more often – weekly, or even several times a week – as opposed to fortnightly or monthly, which is the norm. The result? Life is simpler – and healthier – for you and your staff!



SERVUS SANIPODS ARE:

- **Touch-Free** – Automatic and motion-activated opening for ultra-hygienic sanitary disposal
- **Contemporary** – Innovative design complements all washroom décor and allows for more frequent servicing
- **Compact wall-mounted design** – Maximises utilisation of washroom space, and is easy to clean around and under
- **Ergonomically accessible** – From both standing and sitting positions

Superior Capacity (PER LINER)

Tampon Approx. 220 | Regular Pad Approx. 40

QUICK, SIMPLE 3-STEP SERVICE PROCESS

1

Open door, tear off liner and remove waste



2

Pull down new liner and tie a knot



3

Tuck liner into cavity and close door

